

AirGuard FLD Recommended Disinfectant Instructions

* Using the AG-800 machine, emit a 30-second disinfectant fog blast of FLD fluid for a 10 cubic meter room (about 350 cu.ft.). Larger rooms will require longer blast of fog emission, or the larger AG-1000 machine with higher fog output rate, 30-second disinfectant fog blast of FLD fluid for every 10 cubic meters (about 350 cu.ft.).

*When applying disinfectant fog in cars or rooms with HVAC systems, turn on air conditioners and fans to increase airflow, which helps the spreading of the disinfectant fog and clears the ducting of bacteria as well.

* Recommended cleaning cycle is once every two weeks. The more often the cleaning cycle is carried out, the better sterilization result.

*The chemicals used in the disinfectant fluid are non-toxic and widely used in cosmetics and sanitizers.

* Occasional and brief inhalation of the FLD fog mist is considered safe, however to avoid possible allergic reaction, it is suggested to wait approximately 10 minutes before entering a car or room after the disinfecting fog emission has stopped.